

INSPIRING CONFIDENCE

Universal Wall Box Installation

Surface Mount Installation

Step 1: Determine wall switch mounting location based on wall construction, applicable standards and intended use. In high use and abuse areas, a solid mounting surface or additional reinforcement may be required behind the box.

Step 2: Punch out desired mounting holes in the back of the box shown in the top view drawing at the bottom of the page.


Step 3: Determine stud location in mounting area. Drill holes in mounting surface and into mounting stud.

Step 4: Insert appropriate fastener through box and into mounting surface and tighten securely. For mounting directly into a stud or solid wall, the recommended fastener is a #8-32 x 1" wood screw. For mounting into a hollow wall or surface, the recommended fastener is a #8-32 x 1" toggle bolt. **Step 5:** Complete wall switch assembly using instructions included with your wall switch.


Note:

Labor Saver System can be used to affix mounting boxes to partitions and walls where mechanical fasteners cannot be used. Read and follow the instructions that accompany the Labor Saver System.

Observe all manufacturers recommendations for safety and operation of their products. ANSI/BHMA standards that offer specific recommendations for each type and class of automatic door have been developed. To obtain a copy of the ANSI/BHMA standard that applies to your installation, visit www.buildershardware.com or www.ansi.org.



TOP VIEW DRAWING





INSPIRING CONFIDENCE

Flush Mount Installation

Step 1: Determine wall switch mounting location based on wall construction, applicable standards and intended use. In high use and abuse areas, a solid mounting surface or additional reinforcement may be required behind the box.

Step 2: Determine stud location in mounting area. Cut an access hole adjacent to stud for extra support. Access hole dimensions should be 6-3/4" square for a full sized (6") wall switch and 5-1/4" for a reduced size (4-1/2") wall switch. You can trace around the box as your guide.

Step 3: Punch out holes in box in areas indicated on the top view drawing by the notation "mounting screw punch outs" (see reverse side.


Step 4: Slide the flush mounting ring over the mounting box.

Step 5: Thread two #8-32 screws through the pilot holes into the retaining bracket. Do not tighten screws completely.


Step 6: Insert the mounting box and bracket into the access hole. The bracket is slightly larger than the access hole. Squeeze the sides of the bracket into the mounting box and gently force the bracket through the hole. Tighten both screws until the assembly is held tightly to the wall surface.

Step 7: Complete the wall switch assembly using instructions included with your wall switch.

Universal Wall Box Installation



FLUSH MOUNT KIT ASSEMBLY INSTRUCTIONS



FLUSH MOUNTING ILLUSTRATION

Observe all manufacturers recommendations for safety and operation of their products. ANSI/BHMA standards that offer specific recommendations for each type and class of automatic door have been developed. To obtain a copy of the ANSI/BHMA standard that applies to your installation, visit <u>www.buildershardware</u>.com or www.ansi.org.